

# **VManager AP Bridge User's Guide**

# Table of Contents

---

1	About This Guide	4
1.1	Related Documents	4
1.1.1	Getting Started with a Starter Kit	4
1.1.2	User's Guide	4
1.1.3	Interfaces for Interaction with a Device	4
1.1.4	Access Point Notes	5
1.1.5	Software Development Tools	5
1.1.6	Application Notes	5
1.1.7	Documents Useful When Starting a New Design	5
1.1.8	Software	6
1.1.9	Other Useful Documents	6
1.2	Conventions Used	7
1.3	Revision History	8
2	Introduction	9
3	Installation	10
3.1	Raspberry Pi Software Installation	10
3.2	IP Address Configuration	11
3.3	Adding and Configuring AP Notes	11
3.4	Adding or Removing an AP Mote	12
4	Configuring the AP Bridge	13
4.1	VManager Association	13
4.2	AP Mote Configuration	13
5	CLI Commands	15
5.1	clear	16
5.2	exit/logout/quit	17
5.3	get	18
5.4	help	20
5.5	info	21
5.5.1	VManager info	21
5.5.2	AP Mote info	22
5.5.3	AP Bridge Info	22
5.5.4	GPS Info	22
5.6	set	23
5.7	version	25
5.8	CLI Debug Commands	26
5.8.1	logger	26
5.8.2	reset	27
5.8.3	stats	28
5.8.4	stop	30

---

5.8.5	subscribe/unsubscribe	31
5.8.6	trace	32
6	AP Mote Commands	33
6.1	info	34
6.2	get	35
6.3	set	36
6.4	minfo	37
6.5	mget	38
6.6	mset	39
6.7	reset	40
6.8	Diagnostic and debug commands	41
6.8.1	mfs	41
6.8.2	radiotest	43
6.8.3	trace	48
6.8.4	mtrace	49
6.8.5	stats	50
6.8.6	mlog	51
6.8.7	mxtal	52

# 1 About This Guide

---

## 1.1 Related Documents

---

The following documents are available for the SmartMesh IP network:

### 1.1.1 Getting Started with a Starter Kit

- [SmartMesh VManager Easy Start Guide](#) - walks you through basic VManager installation and a few tests to make sure your network is working.
- [SmartMesh IP Embedded Manager Easy Start Guide](#) - walks you through basic embedded manager installation and a few tests to make sure your network is working.
- [SmartMesh IP Embedded Manager Tools Guide](#) - the installation section contains instructions for installing the serial drivers and example programs used in the Easy Start Guide and other tutorials.

### 1.1.2 User's Guide

- [SmartMesh IP User's Guide](#) - describes network concepts, and discusses how to drive mote and manager APIs to perform specific tasks, e.g. to send data or collect statistics. This document provides context for the API guides. It also contains a glossary of SmartMesh terms.

### 1.1.3 Interfaces for Interaction with a Device

There are two interfaces for interaction with a Manager - an Application Programming Interface (API) for programmatic interaction, and a Command Line Interface (CLI) for human interaction.

- [SmartMesh IP Embedded Manager CLI Guide](#) - used for human interaction with an embedded manager (e.g. during development of a client, or for troubleshooting). This document covers connecting to the CLI and its command set.
- [SmartMesh IP Embedded Manager API Guide](#) - used for programmatic interaction with an embedded manager. This document covers connecting to the API and its command set.
- [SmartMesh IP VManager CLI Guide](#) - used for human interaction with a VManager (e.g. during development of a client, or for troubleshooting). This document covers connecting to the CLI and its command set.
- [SmartMesh IP VManager API Guide](#) - used for programmatic interaction with a VManager. This document covers connecting to the API and its command set.
- [SmartMesh IP Mote CLI Guide](#) - used for human interaction with a mote (e.g. during development of a sensor application, or for troubleshooting). This document covers connecting to the CLI and its command set.

- [SmartMesh IP Mote API Guide](#) - used for programmatic interaction with a mote. This document covers connecting to the API and its command set.

## 1.1.4 Access Point Notes

- [SmartMesh IP User's Guide](#) - describes reprogramming DC2274 for use as an Access Point Mote.
- [VManager AP Bridge User's Guide](#) - user's guide for the Access Point Bridge reference software

## 1.1.5 Software Development Tools

- [Dustcloud.org](#) - contains documentation and links to various open source software tools for exercising mote and manager APIs and visualizing the network.

## 1.1.6 Application Notes

- [SmartMesh IP Application Notes](#) - Cover a wide range of topics specific to SmartMesh IP networks and topics that apply to SmartMesh networks in general.

## 1.1.7 Documents Useful When Starting a New Design

- The Datasheet for the mote being used, e.g. the [LTC5800-IPM SoC](#), or one of the [modules](#) based on it.
- The Datasheet for the embedded manager being used, e.g. the [LTC5800-IPR SoC](#), or one of the [embedded managers](#) based on it.
- A [Hardware Integration Guide](#) for the mote/manager SoC or [module](#) - this discusses best practices for integrating the SoC or module into your design.
- A [Hardware Integration Guide](#) for the embedded manager - this discusses best practices for integrating the embedded manager into your design.
- A [Board Specific Integration Guide](#) - For SoC motes and Managers. Discusses how to set default IO configuration and crystal calibration information via a "fuse table".
- [Hardware Integration Application Notes](#) - contains an SoC design checklist, antenna selection guide, etc.
- The [ESP Programmer Guide](#) - a guide to the DC9010 Programmer Board and ESP software used to load firmware on a device.

## 1.1.8 Software

- ESP software - used to program firmware images onto a mote or module. Described in the [ESP Programmer Guide](#).
- Fuse Table software - used to construct the fuse table as discussed in the [Board Specific Configuration Guide](#).

## 1.1.9 Other Useful Documents

- A list of [Frequently Asked Questions](#).

## 1.2 Conventions Used


---


The following conventions are used in this document:


`Computer type` indicates information that you enter, such as specifying a URL.


**Bold type** indicates buttons, fields, menu commands, and device states and modes.

*Italic type* is used to introduce a new term, and to refer to APIs and their parameters.

 Tips provide useful information about the product.

 Informational text provides additional information for background and context

 Notes provide more detailed information about concepts.

 **Warning!** Warnings advise you about actions that may cause loss of data, physical harm to the hardware or your person.

`code blocks display examples of code`

## 1.3 Revision History

---

Revision	Date	Description
1	12/17/2015	Initial Release
2	08/19/2016	Phase I Production
3	11/07/2016	Clarified stunnel configuration; Described disconnection and reconnection; Numerous small improvements
4	03/15/2017	Minor updates



## 2 Introduction

---

When the Access Points are required to be physically separated from where the VManager is installed, a gateway is required. The gateway could be as simple or as complex as is required for the application, but will typically be a device that acts as a bridge between the AP Motes and a TCP/IP connection to the VManager. That TCP/IP connection could be a standard hard-wired RJ-45 connection, WiFi, Cellular, etc.

For convenience and easy prototyping of a system, an AP Bridge reference gateway has been built for the Raspberry Pi 2 and a fully functional prebuilt image is available for download and installation. The source code and project is also available for anyone who wishes to port to a different Linux based platform, such as a Beagle Bone. Refer to the [AP Bridge Integrator's Guide](#) on [dustcloud.org](http://dustcloud.org) for more information.

## 3 Installation

---

For convenience and easy prototyping of a system, an AP Bridge reference gateway has been built for the Raspberry Pi 2, and the full install image is available through your Linear contact.

### 3.1 Raspberry Pi Software Installation

---

The reference AP Bridge is available as a complete system image. The image is available for download through your [MyLinear](#) account. Contact your local sales representative to gain access through your myLinear document locker.

- raspbian-jessie-lite-dust-XXXX.zip

This file contains the following;

- Raspbian Jessie Lite from [Raspberry Pi official website](#)
- Most recent AP Bridge Software release
- AP Bridge runtime dependencies

Download the .zip file and unzip it to retrieve the *raspbian-jessie-lite.img* file.



It is highly recommended to use a high quality 16 GByte (or larger) Class 10 SD card.

Prepare the SD card - Using a Windows system:

- Download the Win32DiskImager utility from the [Sourceforge Project page](#)
- Extract the executable from the Win32DiskImager .zip file and run the Win32DiskImager utility. You may need to run the utility as administrator by right-clicking the file and select **Run as administrator**.
- Select the image file extracted earlier and write it to the SD card. Be sure to double check that the volume matches that of the SD card, as the utility will erase whatever volume is selected, including your primary system drive.
- After the write finishes, exit Win32DiskImager and eject the SD card.

Complete the installation - On the Raspberry Pi (rPi)

- While powered down, insert your SD card into the rPi
- Connect an HDMI monitor, and a USB keyboard
- Connect an Ethernet cable
- Connect the mini USB power cable to boot
- Once booted, log in (username = dust and password = dust)
- The `raspi-config` utility will appear on the first boot up. Choose option 1 - **Expand File System** (use the tab key to highlight the **Select** button to proceed)


- Once completed, exit and reboot

## 3.2 IP Address Configuration

By default, the rPi uses DHCP to obtain an IP address. If you need to know this address to connect via SSH, use the `ifconfig` command to get the Ethernet (eth0) IP address (inet addr):

```
$ ifconfig
eth0      Link encap:Ethernet  HWaddr b8:27:eb:3d:74:72
          inet addr:10.70.7.138  Bcast:10.70.7.255  Mask:255.255.255.0
...

```

 Refer to the online guides, such as [How to give your Raspberry Pi a Static IP Address](#), for the Jessie release of Raspbian for instructions on how to configure a static IP address if required.

Now that the IP address is known, it will be possible use SSH to connect to the rPi.

```
$ ssh dust@192.168.1.10 -p 22
```

## 3.3 Adding and Configuring AP Motes


The system is now ready for the final installation step, namely adding AP Motes.

- Make sure that the rPi is powered ON
- Connect one or more AP Motes to the USB port

Within a few seconds, the devices should be detected and configured by the software.

To verify that the AP Mote installation was successful, run the following command. An entry should appear for each AP Mote installed.

```
$ apcctl status
apc-30080e          RUNNING      pid 3406, uptime 0:03:30
```

 If an AP mote is plugged in for the first time while the Raspberry Pi either powered OFF or is in the process of booting, the configuration files may not be created automatically. If this happens, remove the AP Motes and re-connect them once the system is completely booted.

## 3.4 Adding or Removing an AP Mote

Additional AP Motes can be added at any time when the system is powered on. The AP Bridge software will automatically recognize an AP Mote and create the required configuration. If an AP Mote is removed from the system, it is recommended to uninstall the matching configuration. While the AP Bridge software remains configured for an unconnected device, the system will attempt to reconnect to the missing device.

To remove a device, unplug it from the rPi USB connector, and follow the steps below to remove the device's configuration.

```
$ apcctl status
apc-30080e                RUNNING    pid 3406, uptime 0:03:30

$ update-apc-config delete --name apc-30080e
```

In the event that all AP Motes on a system need to be swapped, the following commands can be used as a faster way of doing it.

```
$ update-apc-config delete --name all

$ update-apc-config auto
```

## 4 Configuring the AP Bridge

The complete system that has been built by following all of the steps in the [Installation](#) section of this manual is referred to as an "AP Bridge".

The following configurations steps are required to connect the AP Bridge to a VManager so that a network can be formed, or so the AP Bridge can participate in an existing network.

### 4.1 VManager Association

When the AP Bridge is running separately from the VManager host, the AP Bridge must be configured to connect securely to the desired VManager. The connection between the AP Bridge and the VManager is secured by encapsulating the TCP communication with a TLS session using [stunnel](#). The configuration is performed by running the `update-apc-config stunnel` command.



This step is only necessary when the AP Bridge software is running on a separate host from the VManager. Do not perform this step on the VManager VM.


- Login to the AP Bridge host (e.g. a Raspberry Pi) with the "dust" user, either locally or remotely with SSH.
- Execute the following commands

```
$ update-apc-config stunnel --host 10.70.48.46
/opt/dust-apc/etc/stunnel/apc_stunnel.conf created
installed stunnel conf file
Stopping SSL tunnels: [stopped: /etc/stunnel/apc_stunnel.conf] stunnel.
stopped stunnel
started stunnel

$ update-apc-config stunnel
Stunnel configuration
client: yes
accept: 9100
connect: 10.70.48.46:9101
```

### 4.2 AP Mote Configuration

The AP Mote(s) may need to have their configuration changed if the default configuration is not suitable. The only user-settable parameters on the AP Mote are TX power, join key and clock source. These parameters can be changed using the APC CLI Console.

 For the VManager 1.0.1 release, the only supported clock source is the default value, *Auto*.

Each AP Mote connected to the system can be configured individually. There is an instance of the APC software running for each AP Mote connected to the system. The APC CLI Console is used to pass the configuration parameters to the AP Mote. To configure a specific AP Mote:

- Identify the name of the APC process connected to the desired AP Mote by issuing the `apcctl status` command. The last three bytes of the AP Mote MAC address are part of the APC instance name.

```
$ apcctl status
apc-30080e          RUNNING    pid 3967, uptime 0:00:11
apc-6036e3          RUNNING    pid 3851, uptime 0:37:47
```

- Open the AP Bridge CLI. If there is only one AP Bridge running, no parameters are required, otherwise use the `-n` switch with the name of the APC to be configured.

```
$ apc-console -n apc-30080e
Welcome to the APC CLI Console on Linux Version 1.0.1.10
$>
```

- Configure the AP Mote. For example, use the `set` command to specify the join key matching the VManager's ACL.
- Exit the CLI

## 5 CLI Commands

---

The APC Console is written in Python and provides access to the APC components. This component is meant as a reference and a final customer AP Gateway is free to implement part or all of this functionality.

To get into the APC CLI, use the following;

```
apc-console [-n <apc-xxxxxx>]
    If only one APC instance is running on the system, no parameters are required
```

The apc service name can be retrieved with the command "apcctl status"

```
$ apcctl status
apc-30080e          RUNNING      pid 3967, uptime 0:00:11
apc-6036e3         RUNNING      pid 3851, uptime 0:37:47

$ apc-console -n apc-30080e
Welcome to the APC CLI Console on Linux
Version 1.0.1.10
$>
```

## 5.1 clear

---

### Description

This command clears the apc console screen

### Syntax

```
clear
```

### Parameters

Parameter	Description
	This command has no parameters

### Example

```
$> clear
```



## 5.2 exit/logout/quit

---

### Description

This command exits the console.

### Syntax

```
<exit | logout | quit>
```

### Parameters

Parameter	Description
	This command has no parameters

### Example

```
$> logout
```

## 5.3 get

### Description

This command displays information about the APC or AP(s)

### Syntax

```
get <ap|apc> [args]
```

### Parameters

Parameter (one of the following)	Description
ap	Display information about the AP, where [args] is one of <ul style="list-style-type: none"><li>• apInfo</li><li>• apStatus</li><li>• clkSrc</li><li>• macAddr</li><li>• netid</li><li>• time</li><li>• txpwr</li></ul>
apc	Display information about the APC, where [args] is one of <ul style="list-style-type: none"><li>• clientId</li><li>• gpsState</li><li>• managerHost</li><li>• managerPort</li></ul>

### Example

```
$> get ap macAddr
00-17-0D-00-00-12-34-56

$> get ap apstatus
DN_API_ST_OPERATIONAL

$> get apc gpsstate
GPS_ST_NO_DEVICE

$> get ap clksrc
AUTO
```

#### Notes:

- *txpwr* - the get command will return the value selected by the radio driver plus the configured antenna gain value. Refer to the AP Mote Commands section for the procedure for setting the antGain parameter.
- *clkSrc* - the get command will return the configured value for the AP Mote, AUTO or GPS.

## 5.4 help

---

### Description

This command list all commands apc console supports.

### Syntax

```
help
```

### Parameters

Parameter	Description
	This command list all available commands.
command	This command shows detailed help for the command.

### Example

```
$> help
Documented commands (type help <topic>):
=====
clear  get   info  logout  reset  stats  subscribe  unsubscribe
exit  help  logger  quit   set   stop   trace     version
```

## 5.5 info

### Description

This command displays information about the VManager, the AP Mote (AP), the AP Bridge software (APC), and the status of GPS time source.

### Syntax

```
info
```

### Parameters

Parameter	Description
	This command has no parameters

### Example

```
$> info
Manager Host                localhost
Manager Port                9100
Manager State               APCCLIENT_STATE_ONLINE
AP Mac Address              00-17-0D-00-00-30-08-0E
AP State                    DN_API_ST_OPERATIONAL
AP Version                  1.4.0.72
AP Clock Source             DN_API_AP_CLK_SOURCE_INTERNAL
APC Client Id               apc-30080e
APC Version                 1.0.1.3 (built 2016/03/18 13:34:59)
GPS State                   GPS_ST_NO_DEVICE
Satellites Used             0
Satellites Visible         0
```

### 5.5.1 VManager info

- Manager Host - The host name of the VManager. It is configurable in the apc configuration file. With stunnel used, it will be localhost or 127.0.0.1
- Manager Port - The TCP port number that the VManager is monitoring for a connection request
- Manager State - Indicates whether the APC is connected to the VManager, possible values are APCCLIENT\_STATE\_ONLINE or APCCLIENT\_STATE\_OFFLINE

## 5.5.2 AP Mote info

- AP MAC Address - MAC address of the AP
- AP State - One of DN\_API\_ST\_IDLE, DN\_API\_ST\_SEARCHING, DN\_API\_ST\_CONNECTED, or DN\_API\_ST\_OPERATIONAL
- AP Version - The AP software version, it has the same value of "info" from AP CLI.
- AP Clock Source - One of DN\_API\_AP\_CLK\_SOURCE\_INTERNAL, DN\_API\_AP\_CLK\_SOURCE\_NETWORK or DN\_API\_AP\_CLK\_SOURCE\_PPS

## 5.5.3 AP Bridge Info

- APC Client Id - APC client name.
- APC Version - The APC version automatically generated by Dust build system.

## 5.5.4 GPS Info

- GPS State - One of GPS\_ST\_NO\_DEVICE, GPS\_ST\_NO\_SYNC, GPS\_ST\_SYNC or GPS\_ST\_CONN\_LOST
- Satellites Used - The number of satellites locked by the GPS device
- Satellites Visible - The number of satellites tracked by the GPS device

## 5.6 set

### Description

This command is used to set the AP Mote parameters specific to a given deployment. Additionally, the log level for the specified logger can be set.

### Syntax

```
set <ap|loglevel> <arg> <value>
```

### Parameters

Parameter (one of the following)	Description
ap	<p>Set the AP parameter specified by &lt;arg&gt; to &lt;value&gt;. Valid &lt;arg&gt; options are:</p> <ul style="list-style-type: none"> <li>• clkSrc [ AUTO   GPS ]</li> <li>• jkey (in hex)</li> <li>• txpwr</li> </ul>
loglevel	<p>Set the logger specified by &lt;arg&gt; to the log level &lt;value&gt;. Valid loggers are listed by the <code>logger</code> command.</p> <p>The following log levels are available and are specified by name in the &lt;value&gt; field:</p> <ul style="list-style-type: none"> <li>• FATAL (1)</li> <li>• ERR (2)</li> <li>• WARN (3)</li> <li>• INFO (4)</li> <li>• DEBUG (5)</li> <li>• TRACE (6)</li> </ul>

### Example

```
$> set ap clkSrc auto

$> set ap jkey 445553544E4554574F524B53524F434B

$> set loglevel apc INFO
Done
```

#### Notes:

- *clksrc* - By default, the AP Bridge configuration sets the clock source to "Auto". If a GPS time source is used, the AP Bridge configuration must be set to "GPS".
- *jkey* - The AP Mote join key must match the join key specified in the VManager's ACL. This setting is persisted in the AP Mote, however not persisted in the AP Bridge software. This is to allow an *exchangeJoinKey* to be performed by the VManager.
- *txpwr* - The *txpwr* configuration must be set on each AP Mote separately if the default value is not used. The *txpwr* command may be issued at any time and takes effect immediately. If the provided *txpwr* does not match an appropriate value for the hardware, the AP Mote will select the nearest appropriate value. The nearest appropriate value varies depending on the hardware and calibration.



## 5.7 version

---

### Description

This command displays the AP Bridge Console version

### Syntax

```
version
```

### Parameters

Parameter	Description
	This command has no parameters

### Example

```
$> version  
Version 1.0.1.9
```

## 5.8 CLI Debug Commands

The following commands are for intended for the purpose of debugging a system and should not be used under normal circumstances.

### 5.8.1 logger

#### Description

This command lists available loggers or the details about a specific logger

#### Syntax

```
logger [logger_name]
```

#### Parameters

Parameter	Description
logger_name	The name of the logger to display

#### Example

```
$> logger
Loggers: apc, apc.client, apc.io, apc.main, apm, apm.io, apm.io.raw, apm.io.serial, rpc.server,
rpc.worker, rpc.worker.internalcmd

$> logger apc
Logger: apc, rc: 0, logLevel: L_INFO
```

## 5.8.2 reset

### Description

This command resets the AP

### Syntax

```
reset ap
```

### Parameters

Parameter	Description
	This command has no parameters

### Example

```
$> reset ap
```

## 5.8.3 stats

### Description

This command displays or clears the AP or manager stats

### Syntax

```
stats <ap|manager|clear>
```

### Parameters

Parameter (one of the following)	Description
ap	Display APC <-> AP stats
manager	Display APC <-> manager stats
clear	Clear all stats

### Example

```

$> stats
AP/APC Statistics
-----
Packets in Queue                0
Packets Sent                    5,119
Packets Rcvd                    5,119
Responses Rcvd                  5,079
Nacks Sent                      0
Nacks Rcvd                      0
Max Nack Count                  0
Retries Sent                    3
Retries Rcvd                    0
Resp Min (us)                   1,474
Resp Max (us)                   37,853
Resp Avg (us)                   1,925
Time In Queue Min (us)          1,623
Time In Queue Max (us)         815,187
Time In Queue Avg (us)         5,923
Number of output buffers        3
RX Current Rate(pps)            0
30 sec average (pps)            0.000
5 min average (pps)             0.000
total average (pps)             0.008
Manager/APC Statistics
-----
Packets Queued                  0
Packets Sent                    2,467
Packets Rcvd                    2,465
TX delays: <5ms: 2467, <7ms: 0, <10ms: 0, <50ms: 0, >50ms: 0; Max delay: 1.114ms

$> stats clear

```



### APC/AP Statistics

Packets Rcvd includes response and notifications. Usually Packets Rcvd will be bigger than Response Rcvd.

## 5.8.4 stop

### Description

This command unsubscribes to all traces. This is a shortcut and does exactly the same thing as "unsubscribe all"

### Syntax

```
stop
```

### Parameters

Parameter	Description
	This command has no parameters

### Example

```
$> stop
```

## 5.8.5 subscribe/unsubscribe

### Description

This command subscribe or unsubscribe to the specified notification type or all types.

### Syntax

```
subscribe|unsubscribe [notifType|all]
```

### Parameters

Parameter	Description
notifType or all	Subscribe or unsubscribe to the specified notification type or all types

### Example

```
$> subscribe
logListener:
  apc, apc.client, apc.io, apc.main, apm, apm.io, apm.io.raw, apm.io.serial, rpc.server, rpc.worker

$> subscribe apc
Subscribed to apc

$> unsubscribe all
Done
```

## 5.8.6 trace

### Description

This command turns the trace for a specified notification type. The log level must be set to debug or trace to see the enabled trace.

### Syntax

```
trace <notifType|all> <on|off>
```

### Parameters

Parameter	Description
notifType or all	Trace the specified notification type
on or off	Turn the specified trace on or off

### Example

```
$> trace apm.io on
Trace enabled for apm.io

$> logger apm.io
Logger: apm.io, rc: 0, level=logLevel: L_DEBUG
$> set loglevel apm.io trace
Done
$> 2015-12-16 21:10:00.765 apm.io: L_DEBUG Ping interval expired
2015-12-16 21:10:00.769 apm.io: L_DEBUG Sending ping
2015-12-16 21:10:00.773 apm.io: L_DEBUG Sending packet, cmdId: 0x2
2015-12-16 21:10:00.794 apm.io: L_DEBUG INP cmd: 0x2 RSP:2
2015-12-16 21:10:00.797 apm.io: L_DEBUG INP ACK cmd: 0x2 rc: 0x0
2015-12-16 21:10:00.807 apm.io: L_DEBUG AP RX GetParam: paramId=1
2015-12-16 21:10:01.794 apm.io: L_DEBUG Ping interval expired
2015-12-16 21:10:01.795 apm.io: L_DEBUG Sending ping
2015-12-16 21:10:01.799 apm.io: L_DEBUG Sending packet, cmdId: 0x2
2015-12-16 21:10:01.808 apm.io: L_DEBUG INP cmd: 0x2 RSP:0
2015-12-16 21:10:01.809 apm.io: L_DEBUG INP ACK cmd: 0x2 rc: 0x0
2015-12-16 21:10:01.819 apm.io: L_DEBUG AP RX GetParam: paramId=1
2015-12-16 21:10:01.898 apm.io: L_DEBUG INP cmd: 0x27 REQ:0
2015-12-16 21:10:01.900 apm.io: L_TRACE received AP data
2015-12-16 21:10:01.909 apm.io: L_DEBUG OUT ACK cmd:27
2015-12-16 21:10:02.771 apm.io: L_DEBUG INP cmd: 0x27 REQ:2
2015-12-16 21:10:02.776 apm.io: L_TRACE received AP data
...
```



## 6 AP Mote Commands

---

As with a regular Mote, the AP Mote provides a command line interface. This interface should only be used for diagnostic purposes and should not be required for normal use. The only items that must be configured when setting up an AP Mote for use with a manager are typically the join key and the clock source, both of which have been added to the AP Bridge software CLI for convenience. Note that any setting found in the AP Bridge software will take precedence over any setting change made directly on the AP Mote.

Similarly to the IP Mote, the AP Mote CLI can be accessed from any serial terminal program from the AP Bridge host device. If connecting to a DC2274-A with an FTDI serial-to-usb interface, the CLI will be found on the 3rd COM port mapped onto your system.

The default serial port settings are as follows:

- Bits per second: 9600
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: None

On the VManager VM or the Raspberry Pi-based reference design for the AP Bridge, *miniterm.py* can be used to connect to the AP Mote CLI port.

## 6.1 info

---

### Description

Displays information about the application layer.

### Syntax

```
info
```

### Parameters

Parameter	Description
-----------	-------------

### Example

```
> info

AP IP
ver:01.04.00.74
Radio Test: off
```

## 6.2 get

---

### Description

This command allows to get the values of application level configurable parameters.

### Syntax

```
get <parameter>
```

### Parameters

Parameter	Description
sri	Serial Retry Interval (in msec)

### Example

```
> get sri  
20 msec
```

## 6.3 set

---

### Description

This command allows to set application level configurable parameters.

### Syntax

```
set <parameter> <value>
```

### Parameters

Parameter	Description
sri	Serial Retry Interval (in msec). Takes effect after reset

### Example

```
> set sri 500
```

## 6.4 minfo

---

### Description

Displays various information about the AP Mote

### Syntax

```
minfo
```

### Parameters

Parameter	Description
-----------	-------------

### Example

```
> minfo

Net stack 1.4.0.10
state:    Idle
mac:      00:17:0d:00:00:3f:fe:36
moteid:   0
netid:    258
blSwVer:  13
ldrSwVer: 1.0.6.3
board id/rev:0x2/0x3
UTC time: 1025665200.015 sec
reset st: 400
battery:  3553 mV
temp:     27 C
```

## 6.5 mget

### Description

This command is used to retrieve the values of configurable parameters in the network stack.

### Syntax

```
mget <param>
```

### Parameters

Parameter	Description
clkSrc	Clock source (2=GPS PPS, 3=Auto). The default value is "Auto", and values 0 and 1 are reserved.
txpwr	Radio transmit power. The <i>mget txpwr</i> command returns the persistent configuration value, which matches the value from the last <i>mset txpwr</i> command. The persistent value may be different from the value that is used by the radio.
antGain	Antenna gain (signed 8-bit value) - used to properly calculate radiated power. Defaults to +2 dBi
compMode	Constrains AP duty cycle to power-appropriate limits imposed by EN 300 328. 0=off (default), 1 = on.

### Example

```
> mget clkSrc  
clkSrc = 0
```

## 6.6 mset

### Description

This command allows to set configurable parameters in the network stack.

### Syntax

```
mset <param> <value>
```

### Parameters

Parameter	Description
clkSrc	Clock source (2=GPS PPS, 3=Auto). Default is "Auto", and 0 and 1 are reserved  * The reference AP Bridge software settings take precedence and will overwrite any changes made on the AP Mote
txpwr	Radio transmit power. The value takes effect on next transmission. Refer to product datasheets for supported RF output power values. If the provided value does not match an appropriate value for the hardware, the radio driver will select the nearest appropriate value. The nearest appropriate value varies depending on the hardware and calibration. The <i>mset</i> command stores the provided value persistently. The <i>mget txpwr</i> command will return the persistent value. The <i>getParameter&lt;txpwr&gt;</i> API command will return the value selected by the radio driver.
antGain	Antenna gain (INT8S) - needed to properly calculate radiated power. Defaults to +2 dBi
compMode	Constrains AP duty cycle to power-appropriate limits imposed by EN 300 328. 0=off (default), 1 = on.
jkey	Join key (hex)

### Example

```
> mset clkSrc 3
```

## 6.7 reset

---

### Description

Resets the AP

### Syntax

```
reset
```

### Parameters

Parameter	Description
-----------	-------------

### Example

```
> reset
>
AP IP 1.4.0-74 (0x100)
```



## 6.8 Diagnostic and debug commands

### 6.8.1 mfs

#### Description

File system commands. These are intended for debugging.



The zeroize command will render the device inoperable. It must be re-programmed via SPI or JTAG in order to be usable.

#### Syntax

```
mfs <cmd> {-f|-p} [<param>...]
```

#### Parameters

Parameter	Description
cmd	One of:  show - show a list of files (-f) or partitions (-p)  fcs - calculate CRC for a filename (-f <filename>) or partition (-p <parId> <offset> <length>)  del - delete file (-f <filename>)  zeroize <password> - zeroize device keys per FIPS-140 requirements. The password is 57005 (0xDEAD).

#### Example

```
> mfs show -p
ID   Size   Address  Page
  1  32768  0x000b7800  2048  exec
  2  258048 0x00041000  2048  exec
  4  227328 0x00080000  2048
  6   2048 0x000bf800  2048

> mfs show -f
  1mote.cfg      12 shadow
  1ini.cfg       0 shadow
  2main.cfg      8 shadow
```

Partitions:

- ID - the partition ID
- Size - Partition size in bytes
- Address - Starting address of partition
- Page - Page size in bytes
- Pages marked as exec can contain an executable image

Files:

- 1st column - Filename. Files starting with 1 are created by the network stack. Files starting with a 2 are created by the AP Mote application.
- 2nd column - Size in bytes. 0 indicates an empty file
- 3rd column - Indicates whether the file is shadowed (there is a backup copy) or temporary

## 6.8.2 radiotest

### radiotest on/off

#### Description

Enables or disables radiotest mode. Radiotest functionality can be used to exercise the radio for certification and testing purposes. This command takes effect after reboot and the selected mode persists until changed, i.e. if ON, it will remain on even after reset or power cycle until the mode is set to OFF and the AP Mote is rebooted.

#### Syntax

```
radiotest <mode>
```

#### Parameters

Parameter	Description
mode	on = put AP Mote into radiotest mode after reboot off = put AP Mote into normal mode after reboot

#### Example

```
AP IP 1.4.0-74 (0x100)  
>  
> radiotest on  
>  
AP IP 1.4.0-74 (0x200)  
Radio Test on
```

## radiotest tx

### Description

The `radiotest tx` command allows the user to initiate a radio transmission test. This command may only be issued in radiotest mode. These types of transmission tests are supported:

- pk - Packet Transmission
- cm - Continuous Modulation
- cw - Continuous Wave (unmodulated signal)
- pkcca - Packet transmission with clear channel assessment (CCA) enabled

In a packet transmission test, AP Mote generates a *repeatCnt* number of packet sequences. Each sequence consists of up to 10 packets with configurable sizes and delays. Each packet consists of a payload of up to 125 bytes, and a 2-byte 802.15.4 CRC at the end. Byte 0 contains sender's stationId. Bytes 1 and 2 contain the packet number (in big-endian format) that increments with every packet transmitted. Bytes 3..N contain a counter (from 0..N-3) that increments with every byte inside payload. Transmissions occur on the set of channels defined by *chanMask*, selected in pseudo-random order.

In a continuous modulation test, AP Mote generates continuous pseudo-random modulated signal, centered at the specified single channel. The test is stopped by resetting the AP Mote.

In a continuous wave test, the AP Mote generates an unmodulated tone, centered at the specified single channel. The test tone is stopped by resetting the AP Mote.

In a packet transmission with CCA test, the AP Mote is configured identically to that in the packet transmission test, however it does a clear channel assessment before each transmission and aborts that packet if the channel is busy.



Channel numbering is 0-15, corresponding to IEEE 2.4 GHz channels 11-26.

### Syntax

```
radiotest tx <testType> <chanMask> <power> [<stationId> <repeatCnt> {<pkLen><delay>...}]
```

### Parameters

Parameter	Description
testType	Type of tx to initiate: 'pk' = packets, 'cm' = continuous modulation, 'cw' - continuous wave, "pkcca" = packets with CCA.
chanMask	Hexadecimal bitmask of channels (0–15) for the test. Bit 0 corresponds to channel 0. For continuous wave and continuous modulation tests, only one channel should be enabled.
power	Transmit power, in dB.

stationId	Unique (0-255) station id of the sender. Must match station id value of the receiver.
repeatCnt	Number of times to repeat the packet sequence (0=do not stop). Applies only to packet transmission tests.
pkLen	Length of packet (2-125 bytes)
delay	Delay after transmission (in microseconds)

### Example

Initiate packet test on channels 0,1 (chMap=0x03), with output tx power of 0 dBm, station id = 26  
Repeat the sequence 5 times: 50-byte packet, 20ms delay, 30-byte packet, 20msec delay:

```
radiotest tx pk 0x3 0 26 5 50 20000 30 20000
```

Start transmission with continuous modulation on channel 0 with output tx power of 8 dB:

```
radiotest tx cm 0x1 8
```

Start transmission with continuous wave on channel 1 with output tx power of 8 dB:

```
radiotest tx cw 0x2 8
```

## radiotest rx

### Description

The `radiotest rx` command puts the radio into receive mode where statistics on packet reception are collected. The nonzero station id specified must match station id of the sender, which is necessary to isolate traffic of multiple tests running in the same radio space. Statistics may be viewed with the `radiotest stat` command.



Channel numbering is 0-15, corresponding to IEEE 2.4 GHz channels 11-26.

### Syntax

```
radiotest rx <chanMask> <time> <stationId>
```

### Parameters

Parameter	Description
chanMask	Hexadecimal bitmask of channels (0–15) for the test. Bit 0 corresponds to channel 0. Only a single channel may be specified for this command.
time	Duration of receive test, in seconds. 0=do not stop
stationId	Unique (1-255) id of the receiver. Must match sender's station id. Station id 0 may be used to accept packets from any sender.

### Example

```
Put device into receive mode for 60 seconds on channel 2, use station id 26:  
radiotest rx 0x4 60 26
```

## radiotest stat

### Description

This command displays packet reception statistics collected during the previously run `radiotest rx` command. This command may only be used when the device is in radiotest mode.

### Syntax

```
radiotest stat
```

### Parameters

Parameter	Description
-----------	-------------

### Example

```
>radiotest stat
Radio Test Statistics
  OkCnt   : 0
  FailCnt : 0
```

## 6.8.3 trace

### Description

Turn application layer traces on or off. If called with no arguments, returns current state of all traces. If called with the argument 'save' it stores current settings to non-volatile memory.

### Syntax

```
trace [save | {<module>|all on|off}
```

### Parameters

Parameter	Description
save	Saves all current traces
ser	Serial module traces
loc	Local (NET layer) module traces
clk	Clock-source module traces

### Example

```
> trace ser on
> 7578562 : serial_api TX:
  000 : 0f 09 0a 00 00 00 01 01 00 00 00 00
7579121 : serial_api TX:
  000 : 0f 09 0a 00 00 00 01 01 00 00 00 00
7579681 : serial_api TX:
  000 : 0f 09 0a 00 00 00 01 01 00 00 00 00
```



## 6.8.4 mtrace

### Description

Turn various traces on or off. This change is persistent if called with the 'save' parameter. If called with no arguments, returns current state of all mtraces.

### Syntax

```
mtrace [save | {<parameter> on | off}]
```

### Parameters

Parameter	Description
save	Save current mtrace flags to flash
mac	MAC layer TXs and RXs
io	NET layer TXs and RXs

### Example

```
> mtrace mac on
7497319 : MAC R: a=57423 t=7 ch=13 s=5 rc=0 rs=-23 ad=14 q=0,0
7497457 : MAC T: a=57442 t=7 ch=1 d=3 rc=0 ad=0 po=180 pe=460 q=0,0
7498385 : MAC T: a=57570 t=2 ch=0 d=2 rc=0 ad=-20 po=182 pe=460 q=0,0
7500575 : MAC T: a=57872 t=7 ch=3 d=1 rc=0 ad=0 po=180 pe=460 q=0,0
>
> mtrace mac off
```

## 6.8.5 stats

### Description

Displays UART statistics when called with 'get' argument, clears it when called with 'clear' argument.

### Syntax

```
stats { get | clear }
```

### Parameters

Parameter	Description
-----------	-------------

### Example

```
> stats get
UART stats:
Tx total:      15615
Rx total:      0
Tx RtsCts tout: 0
Rx CtsRx tout: 0
Rx EopRts tout: 0
Rx IB tout:    0
Rx DMA miss:   0
errors:        0
  no_first_flag: 0
  no_last_flag: 0
  overflow:      0
  pkg_len:      0
  status:
    crc:         0
    fram:        0
    par:         0
    ofl:         0
    ple:         0
Notif fail:    0
Q cnt:         1
PO:            0
PFE:           0
```

## 6.8.6 mlog

### Description

This command retrieves the internal AP Mote log which may contain debug information based on the last reset.

### Syntax

```
mlog
```

### Parameters

Parameter	Description
-----------	-------------

### Example

```
> mlog
last task: 0
next task: 0
timer:      0x0
IPSR:      0x0
ISR:       no
Low-level log: '<empty>'
```

## 6.8.7 mxtal

### Description

This command is used to determine the optimal trim value to center the 20MHz crystal oscillator frequency given a particular PCB layout and crystal combination. It is used to measure the 20 MHz crystal, after which the user must enter trim values into the device's fuse table for access by software. See the [Board Specific Configuration Guide](#) for fuse table details.

### Syntax

```
mxtal [trim|meas] [<i>|<h>]
```

### Parameters


Parameter	Description
trim	Trims the adjustable load capacitance for the 20MHz crystal to match the frequency reference on the programming board. Outputs the post-trim ppm error and the optimal value of the load-capacitance setting. The trimmed value of the load capacitance is not stored on the device; the function output should be used to determine the the proper value of the load-capacitance setting for the BSP fuse table parameter. This function requires the mote be connected to the programming board. It could take up to 30 sec for command to execute.
meas	Outputs the ppm error of the 20MHz reference with value loaded from the fuse table . This function requires the device be connected to the programming board. It could take up to 30 sec for command to execute.
i   h	Temperature grade, one of i=industrial or h=high temperature - See device datasheet for details. Defaults to i (industrial) if omitted.

### Example

```
> mxtal meas
Fuse Table pullVal used for measurement=95

> mxtal trim i
The optimal pullVal for this board is 90, which yields 0/16 PPM error
```

## Trademarks

Eterna, Mote-on-Chip, and SmartMesh IP, are trademarks of Dust Networks, Inc. The Dust Networks logo, Dust, Dust Networks, and SmartMesh are registered trademarks of Dust Networks, Inc. LT, LTC, LTM and  are registered trademarks of Linear Technology Corp. All third-party brand and product names are the trademarks of their respective owners and are used solely for informational purposes.

## Copyright

This documentation is protected by United States and international copyright and other intellectual and industrial property laws. It is solely owned by Linear Technology and its licensors and is distributed under a restrictive license. This product, or any portion thereof, may not be used, copied, modified, reverse assembled, reverse compiled, reverse engineered, distributed, or redistributed in any form by any means without the prior written authorization of Linear Technology.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g) (2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015 (b)(6/95) and DFAR 227.7202-3(a), and any and all similar and successor legislation and regulation.

## Disclaimer

This documentation is provided “as is” without warranty of any kind, either expressed or implied, including but not limited to, the implied warranties of merchantability or fitness for a particular purpose.

This documentation might include technical inaccuracies or other errors. Corrections and improvements might be incorporated in new versions of the documentation.

Linear Technology does not assume any liability arising out of the application or use of any products or services and specifically disclaims any and all liability, including without limitation consequential or incidental damages.

Linear Technology products are not designed for use in life support appliances, devices, or other systems where malfunction can reasonably be expected to result in significant personal injury to the user, or as a critical component in any life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness. Linear Technology customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify and hold Linear Technology and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Linear Technology was negligent regarding the design or manufacture of its products.

Linear Technology reserves the right to make corrections, modifications, enhancements, improvements, and other changes to its products or services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to Dust Network's terms and conditions of sale supplied at the time of order acknowledgment or sale.

Linear Technology does not warrant or represent that any license, either express or implied, is granted under any Linear Technology patent right, copyright, mask work right, or other Linear Technology intellectual property right relating to any combination, machine, or process in which Linear Technology products or services are used. Information published by Linear Technology regarding third-party products or services does not constitute a license from Linear Technology to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from Linear Technology under the patents or other intellectual property of Linear Technology.

Dust Networks, Inc is a wholly owned subsidiary of Linear Technology Corporation.

© Linear Technology Corp. 2012-2016 All Rights Reserved.