



MAX6581评估板

评估板: MAX6581

概述

MAX6581评估板(EV kit)是完全安装并经过测试的PCB,用于评估MAX6581 8通道温度传感器。器件监测自身管芯的温度和多达7个外部连接成二极管的晶体管温度。器件将温度转换为8位或11位、2线串行数据,可通过2线串行总线访问。

评估板还包括Windows® 2000、Windows XP®和Windows Vista®兼容软件,为评估器件的功能特性提供简捷的用户界面。程序采用菜单驱动,提供图形用户界面(GUI),具有完整的控制按钮和状态显示。

特性

- ◆ 7个远端温度传感器
- ◆ 本地温度传感器
- ◆ 可编程低温和高温报警
- ◆ 2路开漏输出报警指示($\overline{\text{ALERT}}$ 和 $\overline{\text{OVERT}}$)
- ◆ 板载微控制器,产生SMBus™/I²C命令
- ◆ 使用简单的菜单驱动软件
- ◆ 完全安装并经过测试

订购信息

PART	TYPE
MAX6581EVKIT+	EV Kit

+表示无铅(Pb)并符合RoHS标准。

元件列表

DESIGNATION	QTY	DESCRIPTION
C1, C4-C8, C12, C17, C19	9	0.1 μ F \pm 10%, 16V X7R ceramic capacitors (0603) TDK C1608X7R1C104K Murata GRM188R71C104K
C2, C13, C15	3	10 μ F \pm 20%, 16V X5R ceramic capacitors (1206) Murata GRM31CR61C106M or TDK C3216X5R1C106M
C3	1	4.7 μ F \pm 10%, 6.3V X5R ceramic capacitor (0603) TDK C1608X5R0J475K Murata GRM188R60J475K
C9	1	0.033 μ F \pm 10%, 16V X5R ceramic capacitor (0603) Murata GRM188R71E333K TDK C1608X7R1E333K
C10, C11	2	22pF \pm 5%, 50V C0G ceramic capacitors (0603) Murata GRM1885C1H220J TDK C1608C0G1H220J

DESIGNATION	QTY	DESCRIPTION
C14	1	1 μ F \pm 10%, 16V X5R ceramic capacitor (0603) TDK C1608X5R1C105K Murata GRM188R61C105K
C16, C18	2	10pF \pm 5%, 50V C0G ceramic capacitors (0603) Murata GRM1885C1H100J TDK C1608C0G1H100J
C20-C26	7	100pF \pm 5%, 50V C0G ceramic capacitors (0603) Murata GRM1885C2A101J TDK C1608C0G1H101J
D1, D2	2	Red LEDs (0805)
D3	1	Green LED (0805)
FB1	1	70 Ω , 4A ferrite bead (0603) TDK MMZ1608R301A Murata BLM18SG700 TN1
H1	0	Not installed, 2 x 5-pin JTAG header
JU1-JU8	8	2-pin headers
JU9	1	3-pin header

Windows、Windows XP和Windows Vista是Microsoft Corp.的注册商标。

SMBus是Intel Corp.的商标。



本文是英文数据资料的译文,文中可能存在翻译上的不准确或错误。如需进一步确认,请在您的设计中参考英文资料。

有关价格、供货及订购信息,请联络Maxim亚洲销售中心:10800 852 1249 (北中国区),10800 152 1249 (南中国区),或访问Maxim的中文网站:china.maxim-ic.com。

MAX6581评估板

评估板: MAX6581

元件列表(续)

DESIGNATION	QTY	DESCRIPTION
P1	1	USB type-B right-angle PC-mount receptacle
Q1-Q7	7	2N3906-type pnp transistors (SOT23) Central Semi CMPT3906 Diodes Inc. MMBT3906
R1, R2	2	27 Ω \pm 5% resistors (0603)
R3, R17, R18	3	1.5k Ω \pm 5% resistors (0603)
R4, R7, R19, R20	4	470 Ω \pm 5% resistors (0603)
R5	1	2.2k Ω \pm 5% resistor (0603)
R6, R21	2	10k Ω \pm 5% resistors (0603)
R8	1	0 Ω resistor (0603)
R9, R10, R11-R16	0	Not installed, resistors (0603) R9, R10, R11 are open; R12-R16 are short PC trace
U1	1	8-channel temp sensor (24 TQFN) Maxim MAX6581TG9A+

DESIGNATION	QTY	DESCRIPTION
U2	1	LDO regulator (5 SC70) Maxim MAX8511EXK33+
U3	1	Microcontroller (68 QFN-EP*) Maxim MAXQ2000-RAX+
U4	1	LDO regulator (5 SC70) Maxim MAX8511EXK25+
U5	1	USB-to-UART converter (32 TQFP)
U6	1	93C46-type 3-wire EEPROM (8 SO)
Y1	1	16MHz crystal (HCM49) Hong Kong X'tals SSM1600000E18FAF
Y2	1	6MHz crystal (HCM49) Hong Kong X'tals SSL600000E18FAF
—	9	Shunts (JU1-JU9)
—	1	PCB: MAX6581 EVALUATION KIT+

*EP = 裸焊盘。

元件供应商

SUPPLIER	PHONE	WEBSITE
Central Semiconductor Corp.	631-435-1110	www.centralsemi.com
Diodes Incorporated	805-446-4800	www.diodes.com
Hong Kong X'tals Ltd.	852-35112388	www.hongkongcrystal.com
Murata Electronics North America, Inc.	770-436-1300	www.murata-northamerica.com
TDK Corp.	847-803-6100	www.component.tdk.com

注: 在联系这些元件供应商时, 请说明您使用的是MAX6581。

MAX6581评估文件

FILE	DESCRIPTION
INSTALL.EXE	Installs the EV kit files on your computer
MAX6581.EXE	Application program
FTD2XX.INF	USB driver file
UNINST.INI	Uninstalls the EV kit software
USB_Driver_Help.PDF	USB driver installation help file

MAX6581评估板

评估板: MAX6581

快速入门

推荐设备

- MAX6581评估板(含USB电缆)
- 用户提供的具有空闲USB口的Windows 2000、Windows XP或Windows Vista PC

注：以下章节中，与软件相关的条目用粗体字表示。粗体字表示直接由评估软件提供的条目，粗体字加下划线表示与Windows操作系统相关的条目。

步骤

评估板已完全安装并经过测试。按照以下步骤验证评估板的工作情况。**注意：在完成全部连接之前，请勿打开电源。**

- 1) 从 china.maxim-ic.com/evkitsoftware 下载最新版本的评估软件6581Rxx.ZIP。将评估软件保存至一个临时文件夹，然后解压缩ZIP文件。
- 2) 运行临时文件夹中的INSTALL.EXE程序，在计算机上安装评估软件。该程序文件将被复制并在Windows的 **Start | Programs** 菜单中创建图标。
- 3) 确认全部跳线(JU1至JU9)位于其默认位置，如表1所示。
- 4) 用USB电缆连接PC和评估板。第一次安装USB驱动时，会弹出 **New Hardware Found** 窗口。如果30s后仍未出现与以上所述类似的窗口，请从评估板拔下USB电缆，然后重新连接。在Windows中安装USB设备驱动需要管理员权限。
- 5) 按照 **Add New Hardware Wizard** 中的说明安装USB设备驱动。选择 **Search for the best driver for your device** 选项。利用 **Browse** 按钮，将设备驱动的位置指向 **C:\Program**

Files\MAX6581 (默认安装目录)。安装设备驱动时，Windows可能会显示一条警告消息，提示Maxim使用的设备驱动不包含数字签名。这不是错误，可继续安全安装。更多信息请参考随软件提供的USB_Driver_Help.PDF文件。

- 6) 点击 **Start | Programs** 中的图标，启动评估软件。评估软件主窗口如图1所示，程序自动检测器件地址并启动主程序。

软件详细说明

用户界面

MAX6581评估板的用户界面非常容易使用。每个按钮都与命令和配置字节中的位相对应。通过点击这些按钮，产生正确的I²C兼容写操作，更新MAX6581的内部寄存器。

自动读取

程序轮询器件，查找最新的温度和状态数据，最大速率为每秒两次(2Hz)。如需禁用数据轮询，取消选中程序顶部的 **Auto Read** 选择框。

数据记录

选中程序顶部的 **Data Logging** 选择框，激活数据记录功能。数据记录功能将温度和状态数据保存至文本文件，包括紧邻每个数据点的时间/日期标记。如果选中 **Auto Read** 选择框，则以2Hz的速率采样数据；然而，只有在温度或状态发生变化后才会将数据记录至文件。这样就减缓了数据记录文件的增大。未选中 **Auto Read** 选择框时，每次从 **Options** 菜单栏上选择 **Read All** 时记录数据。取消选中 **Data Logging** 选择框，停止数据记录。

表1. 跳线说明(JU1至JU9)

JUMPER	SHUNT POSITION	DESCRIPTION
JU1-JU7	Installed*	The EV kit uses the 2N3906 transistors as the external diode-connected transistors.
	Not installed	The EV kit uses user-supplied external diode-connected transistors.
JU8	Installed	\overline{STBY} logic-low places the device in standby mode.
	Not installed*	\overline{STBY} logic-high places the device in normal mode.
JU9	1-2*	Connects the device to the on-board 3.3V supply.
	2-3	Connects the device to the user-supplied (3V to 3.6V) supply.

*默认位置。

MAX6581评估板

温度

远端二极管测量通道可提供11位数据(1 LSB = +0.125°C)。8个最高有效位(MSB)可从本地温度和远端温度寄存器读取。用于远端的其余3位可从扩展温度寄存器读取。通过选中 **Temperature** 标签页中的 **Enable Extended Resolution (0x57)** 选择框, 使能扩展分辨率(图1)。

点击 **Read** 按钮读取温度。温度读数(单位为摄氏度)显示在 GUI 右侧。

ALERT和OVERT温度限值

所有温度通道均具有可编程报警(ALERT)和过热(OVERT)门限。报警和过热限值可在 **Temperature** 标签页中的 **ALERT Temperature Limit (0x17)** 和 **OVERT Temperature Limit (0x20)** 组合框中设置(图1)。

点击 **Read** 按钮读取限值。限值(单位为摄氏度)显示在编辑区中。通过在相应编辑区中输入数值(单位为摄氏度), 然后点击 **Write** 按钮可修改限值。




图1. MAX6581评估软件主窗口(温度标签页)

MAX6581评估板

评估板: MAX6581

配置、ALERT屏蔽和OVERT屏蔽寄存器

配置寄存器控制待机模式位、上电复位位、SMBus超时使能位和扩展范围使能位。ALERT屏蔽寄存器使能或禁用ALERT中断输出。OVERT屏蔽寄存器使能或禁用OVERT中断输出。

图2所示为配置寄存器的选择框。每个选择框对应寄存器中的一位。表2、表3和表4说明了Configuration标签页的组合框中每个选择框的功能。

点击Read按钮读取寄存器。选中或取消选中相应的功能，然后点击Write按钮，即可修改寄存器。

状态寄存器功能

Alert High Status (0x44)、OVERT Status (0x45)、Diode Fault Status (0x46)和Alert Low Status (0x47)组合框监测4个状态寄存器，并显示发生的关键状态和故障状态。状态条件列表请参见表5至表8。

点击每个组合框中的Read Status按钮，读取每个寄存器的状态。

Alert High Status (0x44)组合框指示实测的本地或远端温度是否超过了ALERT上限寄存器中设置的对应门限值。

OVERT Status (0x45)组合框指示实测的温度是否超过了OVERT上限寄存器中设置的对应门限值。




图2. MAX6581评估软件主窗口(配置标签页)

MAX6581评估板

表2. 配置寄存器选择框

BIT	NAME	STATE	DESCRIPTION
7	STOP	Checked	Places the device in software standby mode.
		Unchecked*	Places the device in operational mode.
6	POR	Checked	Resets all registers to their default values, including the global configuration register. After selecting the POR checkbox, the checkbox returns to the unchecked state.
		Unchecked*	Normal operation.
5	TIMEOUT	Checked	Disables SMBus timeout.
		Unchecked*	Enables the SMBus timeout.
4	RESERVED	N/A	Not used.
3	RESERVED	N/A	Not used.
2	RESERVED	N/A	Not used.
1	EXTRANGE	Checked	Temperature and limit data range set to -64°C to +191°C.
		Unchecked*	Temperature and limit data range set to 0 to +255°C.
0	RESERVED	N/A	Not used.

*上电复位(POR)状态。

表3. ALERT屏蔽寄存器选择框

BIT	NAME	STATE	DESCRIPTION
7	Mask $\overline{\text{ALERT}}_7$	Checked	Disables the remote-diode 7 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 7 $\overline{\text{ALERT}}$ interrupt.
6	Mask Local $\overline{\text{ALERT}}$	Checked	Disables the local $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the local $\overline{\text{ALERT}}$ interrupt.
5	Mask $\overline{\text{ALERT}}_6$	Checked	Disables the remote-diode 6 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 6 $\overline{\text{ALERT}}$ interrupt.
4	Mask $\overline{\text{ALERT}}_5$	Checked	Disables the remote-diode 5 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 5 $\overline{\text{ALERT}}$ interrupt.
3	Mask $\overline{\text{ALERT}}_4$	Checked	Disables the remote-diode 4 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 4 $\overline{\text{ALERT}}$ interrupt.
2	Mask $\overline{\text{ALERT}}_3$	Checked	Disables the remote-diode 3 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 3 $\overline{\text{ALERT}}$ interrupt.
1	Mask $\overline{\text{ALERT}}_2$	Checked	Disables the remote-diode 2 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 2 $\overline{\text{ALERT}}$ interrupt.
0	Mask $\overline{\text{ALERT}}_1$	Checked	Disables the remote-diode 1 $\overline{\text{ALERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 1 $\overline{\text{ALERT}}$ interrupt.

*上电复位(POR)状态。

表4. OVERT屏蔽寄存器选择框

BIT	NAME	STATE	DESCRIPTION
7	Mask $\overline{\text{OVERT}}_7$	Checked	Disables the remote-diode 7 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 7 $\overline{\text{OVERT}}$ interrupt.
6	Mask Local $\overline{\text{OVERT}}$	Checked	Disables the local $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the local $\overline{\text{OVERT}}$ interrupt.
5	Mask $\overline{\text{OVERT}}_6$	Checked	Disables the remote-diode 6 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 6 $\overline{\text{OVERT}}$ interrupt.
4	Mask $\overline{\text{OVERT}}_5$	Checked	Disables the remote-diode 5 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 5 $\overline{\text{OVERT}}$ interrupt.
3	Mask $\overline{\text{OVERT}}_4$	Checked	Disables the remote-diode 4 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 4 $\overline{\text{OVERT}}$ interrupt.
2	Mask $\overline{\text{OVERT}}_3$	Checked	Disables the remote-diode 3 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 3 $\overline{\text{OVERT}}$ interrupt.
1	Mask $\overline{\text{OVERT}}_2$	Checked	Disables the remote-diode 2 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 2 $\overline{\text{OVERT}}$ interrupt.
0	Mask $\overline{\text{OVERT}}_1$	Checked	Disables the remote-diode 1 $\overline{\text{OVERT}}$ interrupt.
		Unchecked*	Enables the remote-diode 1 $\overline{\text{OVERT}}$ interrupt.

*上电复位(POR)状态。

表5. ALERT高状态寄存器

BIT	NAME	FUNCTION
7	Remote $\overline{\text{ALERT}}_7$	The channel 7 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 7 $\overline{\text{ALERT}}$ High Limit register.
6	Local $\overline{\text{ALERT}}$	The local temperature exceeds the temperature threshold limit in the local $\overline{\text{ALERT}}$ High Limit register.
5	Remote $\overline{\text{ALERT}}_6$	The channel 6 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 6 $\overline{\text{ALERT}}$ High Limit register.
4	Remote $\overline{\text{ALERT}}_5$	The channel 5 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 5 $\overline{\text{ALERT}}$ High Limit register.
3	Remote $\overline{\text{ALERT}}_4$	The channel 4 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 4 $\overline{\text{ALERT}}$ High Limit register.
2	Remote $\overline{\text{ALERT}}_3$	The channel 3 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 3 $\overline{\text{ALERT}}$ High Limit register.
1	Remote $\overline{\text{ALERT}}_2$	The channel 2 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 2 $\overline{\text{ALERT}}$ High Limit register.
0	Remote $\overline{\text{ALERT}}_1$	The channel 1 remote-diode temperature exceeds the programmed temperature threshold limit in the remote 1 $\overline{\text{ALERT}}$ High Limit register.

MAX6581评估板

表6. $\overline{\text{OVERT}}$ 状态寄存器

BIT	NAME	FUNCTION
7	Remote $\overline{\text{OVERT}}$ 7	The channel 7 remote-diode temperature exceeds the temperature threshold limit in the remote 7 $\overline{\text{OVERT}}$ High Limit register.
6	Local $\overline{\text{OVERT}}$	Local Channel Overtemperature Status Bit. This bit is set to logic 1 when the local temperature exceeds the temperature threshold limit in the local $\overline{\text{OVERT}}$ High Limit register.
5	Remote $\overline{\text{OVERT}}$ 6	The channel 6 remote-diode temperature exceeds the temperature threshold limit in the remote 6 $\overline{\text{OVERT}}$ High Limit register.
4	Remote $\overline{\text{OVERT}}$ 5	The channel 5 remote-diode temperature exceeds the temperature threshold limit in the remote 5 $\overline{\text{OVERT}}$ High Limit register.
3	Remote $\overline{\text{OVERT}}$ 4	The channel 4 remote-diode temperature exceeds the temperature threshold limit in the remote 4 $\overline{\text{OVERT}}$ High Limit register.
2	Remote $\overline{\text{OVERT}}$ 3	The channel 3 remote-diode temperature exceeds the temperature threshold limit in the remote 3 $\overline{\text{OVERT}}$ High Limit register.
1	Remote $\overline{\text{OVERT}}$ 2	The channel 2 remote-diode temperature exceeds the temperature threshold limit in the remote 2 $\overline{\text{OVERT}}$ High Limit register.
0	Remote $\overline{\text{OVERT}}$ 1	The channel 1 remote-diode temperature exceeds the temperature threshold limit in the remote 1 $\overline{\text{OVERT}}$ High Limit register.

表7. 二极管故障状态寄存器

BIT	NAME	FUNCTION
7	RESERVED	Not used.
6	Diode Fault 7	DXP7 and DXN7 are open circuit or when DXP7 is connected to VCC.
5	Diode Fault 6	DXP6 and DXN6 are open circuit or when DXP6 is connected to VCC.
4	Diode Fault 5	DXP5 and DXN5 are open circuit or when DXP5 is connected to VCC.
3	Diode Fault 4	DXP4 and DXN4 are open circuit or when DXP4 is connected to VCC.
2	Diode Fault 3	DXP3 and DXN3 are open circuit or when DXP3 is connected to VCC.
1	Diode Fault 2	DXP2 and DXN2 are open circuit or when DXP2 is connected to VCC.
0	Diode Fault 1	DXP1 and DXN1 are open circuit or shorted together.

Diode Fault Status (0x46)组合框指示在任何远端检测通道中是否存在二极管故障(开路或短路)。

Alert Low Status (0x47)组合框指示实测的本地或远端温度是否已经下降至低于ALERT下限寄存器(ALERT Low Limit All Channels (0x30))中设置的门限值。

电阻抵消

所有远端通道均具有电阻抵消功能,以补偿电路板走线和温度二极管中较大的串联电阻。表9给出了Resistance Cancellation (0x4A)标签页中的每个选择框的功能。

点击Read按钮读取寄存器。选中或取消选中相应的功能,然后点击Write按钮,即可修改寄存器。

表8. ALERT \bar 低状态寄存器

BIT	NAME	FUNCTION
7	Remote ALERT \bar 7	The channel 7 remote-diode temperature falls below the programmed temperature threshold limit in the remote 7 ALERT \bar Low Limit register.
6	Local ALERT \bar	The local channel remote-diode temperature falls below the programmed temperature threshold limit in the local ALERT \bar Low Limit register.
5	Remote ALERT \bar 6	The channel 6 remote-diode temperature falls below the programmed temperature threshold limit in the remote 6 ALERT \bar Low Limit register.
4	Remote ALERT \bar 5	The channel 5 remote-diode temperature falls below the programmed temperature threshold limit in the remote 5 ALERT \bar Low Limit register.
3	Remote ALERT \bar 4	The channel 4 remote-diode temperature falls below the programmed temperature threshold limit in the remote 4 ALERT \bar Low Limit register.
2	Remote ALERT \bar 3	The channel 3 remote-diode temperature falls below the programmed temperature threshold limit in the remote 3 ALERT \bar Low Limit register.
1	Remote ALERT \bar 2	The channel 2 remote-diode temperature falls below the programmed temperature threshold limit in the remote 2 ALERT \bar Low Limit register.
0	Remote ALERT \bar 1	The channel 1 remote-diode temperature falls below the programmed temperature threshold limit in the remote 1 ALERT \bar Low Limit register.

表9. 电阻抵消寄存器(4Ah)

BIT	NAME	STATE	DESCRIPTION
7	X	—	Not used.
6	RESISTANCE CANCELLATION 7	Checked	Enables channel 7 resistance cancellation.
		Unchecked*	Disables channel 7 resistance cancellation.
5	RESISTANCE CANCELLATION 6	Checked	Enables channel 6 resistance cancellation.
		Unchecked*	Disables channel 6 resistance cancellation.
4	RESISTANCE CANCELLATION 5	Checked	Enables channel 5 resistance cancellation.
		Unchecked*	Disables channel 5 resistance cancellation.
3	RESISTANCE CANCELLATION 4	Checked	Enables channel 4 resistance cancellation.
		Unchecked*	Disables channel 4 resistance cancellation.
2	RESISTANCE CANCELLATION 3	Checked	Enables channel 3 resistance cancellation.
		Unchecked*	Disables channel 3 resistance cancellation.
1	RESISTANCE CANCELLATION 2	Checked	Enables channel 2 resistance cancellation.
		Unchecked*	Disables channel 2 resistance cancellation.
0	RESISTANCE CANCELLATION 1	Checked	Enables channel 1 resistance cancellation.
		Unchecked*	Disables channel 1 resistance cancellation.

X = 无关。

*上电复位(POR)状态。

MAX6581评估板

高级用户界面

有两种方法可与器件通信：通过标准用户界面主窗口或通过SMBus/I²C命令，后者可从菜单栏中选择Options | Interface (Advanced Users)获得。软件会弹出Advanced User Interface窗口，其中已选中2-wire interface标签页，利用它可执行SMBus/I²C兼容协议，例如：读字节和写字节。器件使用的唯一SMBus/I²C兼容协议为：

- 1 - SMBusWriteByte(addr,cmd,data8)
- 4 - SMBusReadByte(addr,cmd) → data8

组合框和编辑框接受十六进制的数字数据，并且应以0x开始。请参考图3中的工具示例。

在本例中，软件从Device Address 10011010 r/w（二进制）、寄存器地址0x07读取数据。

硬件详细说明

MAX6581评估板为完全安装并经过测试的PCB，用于评估MAX6581 8通道温度传感器。器件监测其自身管芯温度和多达7个外部连接成二极管的晶体管温度。评估板具有板载微控制器，可通过USB端口从PC接收命令。评估板可由USB或3.3V单电源电压直接供电。




图3. 利用高级用户界面进行简单的SMBusReadByte操作示例

MAX6581评估板

评估板: MAX6581

更换二极管

跳线 JU1 至 JU7 将 2N3906 晶体管连接为外部二极管。如需使用不同的二极管，请移除 Q1 至 Q7，然后将二极管(利用双绞线)连接在 DXP1 至 DXP7 和 DXN1 至 DXN7 焊盘之间。

用户提供的电源

评估板在默认情况下完全由 USB 端口供电。如需从外部为评估板供电，请将跳线 JU9 上的短路器移至 2-3 位置，并在 VCC 和 GND 焊盘上施加用户提供的 3.3V 电源。

MAX6581评估板




图4a. MAX6581评估板原理图(1/2)

MAX6581评估板

评估板: MAX6581




图4b. MAX6581评估板原理图(2/2)



MAX6581评估板

评估板: MAX6581




图5. MAX6581评估板元件布局—元件层




图6. MAX6581评估板PCB布局—元件层




图7. MAX6581评估板PCB布局—焊接层

MAX6581评估板

修订历史

修订号	修订日期	说明	修改页
0	9/10	最初版本。	—

评估板: MAX6581

Maxim北京办事处

北京8328信箱 邮政编码 100083

免费电话: 800 810 0310

电话: 010-6211 5199

传真: 010-6211 5299

Maxim不对Maxim产品以外的任何电路使用负责, 也不提供其专利许可。Maxim保留在任何时间、没有任何通报的前提下修改产品资料和规格的权利。

Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600 _____ 15

© 2010 Maxim Integrated Products

Maxim是Maxim Integrated Products, Inc.的注册商标。