



Linear Tech. Corp.  
Demo Circuit 1538A

Silkscreen Top

ASSY TOP

## NOTES : Unless Otherwise Specified

1. BREAK BOARDS FROM THE PANEL WHEN ASSEMBLY IS COMPLETE.
2. OPTIONAL COMPONENTS ARE UNSTUFFED AND SHOULD BE FREE OF SOLDER AFTER ASSEMBLY.
3. JUMPER SHUNT INSTALLATIONS:

JP1: ENABLE  
JP2: DC  
JP3: NC  
JP4: DC  
JP5: EXT  
JP6: Single Supply