


**INSTALL STANDOFF ON System Backplane BOARD ONLY. 4 PCS.**

**NOTES : Unless Otherwise Specified**

1. BREAK BOARDS FROM THE PANEL WHEN ASSEMBLY IS COMPLETE.
2. OPTIONAL COMPONENTS ARE UNSTUFFED AND SHOULD BE FREE OF SOLDER AFTER ASSEMBLY.
3. JUMPER SHUNTS INSTALLATION: JP1: GND; JP2: +5V; JP3: +5V;
4. DO NOT PUT TWO BOARDS TOGETHER.(DO NOT INSERT J1 TO P1).

## Assembly Top Drawing

APPROVALS				 <div>1630 McCarthy Blvd. Milpitas, CA 95035 PH: (408)432-1900</div>		
		INIT	DATE			
DRAWN						
CHECK						
DESIGN	June Wu		12/5/05	TITLE: LTC1644CGN		
ENGR	A. Gardner		12/5/05	CompactPCI Bus Hot Swap Controller		
				SIZE	DEMO NO.	REV.
				A	DC461A	A
SCALE = NONE				DES-250019 SH1 of 1		

