



Board Platform:
Programming-Adapter

Interfaces:
JTAG

Voltage:
3.5–5.5V

Current:
300mA

www.TRINAMIC.com

v3.0



open source
hardware