

Changes to Table 3

| | From | To |
|------------------|-----------------|-----------------|
| Vin to GND | "-0.3V to 3.6V" | "-0.3V to 4.0V" |
| Vout to GND | "-0.3V to 3.6V" | "-0.3V to VIN" |
| EN to GND | "-0.3V to 3.6V" | "-0.3V to VIN" |
| SS to GND | "-0.3V to 3.6V" | "-0.3V to VIN" |
| PG to GND | "-0.3V to 3.6V" | "-0.3V to 4.0V" |
| Sense/ADJ to GND | "-0.3V to 3.6V" | "-0.3V to VIN" |