

## Evaluating the **AD9912** 1 GSPS Direct Digital Synthesizer with 14-Bit DAC

### FEATURES

- Flexible system clock input accepts crystal, crystal oscillator, or external reference clock
- Dedicated pad for mounting crystal or crystal oscillator
- DAC output easily accessible via SMA connector
- SMA connectors provided for external reconstruction filter
- Easy to use Windows graphical user interface
- Software control of all **AD9912** features
- Power supplies that are easily separated
- Connection via USB port
- Dedicated SMA connectors for CMOS, DAC, and HSTL outputs
- Residual phase noise at 250 MHz
  - 10 Hz offset:  $-113$  dBc/Hz
  - 1 kHz offset:  $-133$  dBc/Hz
  - 100 kHz offset:  $-153$  dBc/Hz
  - 40 MHz offset:  $-161$  dBc/Hz

### PACKAGE CONTENTS

- AD9912** evaluation board
- USB cable

### ONLINE RESOURCES

Note that the following items can be downloaded from the [AD9912 Evaluation Board](http://www.analog.com) page at [www.analog.com](http://www.analog.com):

- Evaluation software
- Instructions
- Data sheet
- Schematics

### GENERAL DESCRIPTION

The **AD9912** evaluation board is an evaluation platform for the **AD9912** direct digital synthesizer (DDS). It easily connects to a host computer via a USB interface and allows easy access to all **AD9912** features via the Windows®-based evaluation software and graphical user interface.

This document provides instructions for the setup and installation of the board and software and includes a description of the various software menus and hardware connections. Additional evaluation board details, such as schematics, are available on the **AD9912** evaluation board page at [www.analog.com](http://www.analog.com).

This document covers both Revision A and Revision B of the **AD9912** evaluation board. The two versions differ in that Revision B has a convenient connection for a 1 kΩ pull-down resistor on the loop filter pin, whereas Revision A does not. Please note that Revision A of the **AD9912** evaluation board is no longer in production.

The **AD9912A/PCBZ** operates over an industrial temperature range, spanning  $-40^{\circ}\text{C}$  to  $+85^{\circ}\text{C}$ .

### EVALUATION BOARD BLOCK DIAGRAM




Figure 1.

## TABLE OF CONTENTS

Features .....	1	Evaluation Software Main Window .....	6
Package Contents .....	1	Interactive Block Diagram .....	6
Online Resources .....	1	Menu Bar .....	6
General Description .....	1	Button Bar .....	7
Evaluation Board Block Diagram .....	1	Evaluation Software Functional Blocks .....	8
Revision History .....	2	Interactive Block Diagram .....	8
Evaluation Board Physical Connections .....	3	S-Divider Settings Window .....	8
Power Connections .....	3	DDS and Clock Multiplier Control.....	8
Connections to PC .....	3	CMOS Driver and Clock Out.....	8
Signal Connections .....	3	Status and IRQ Control Window .....	8
Using an Oscillator for the System Clock.....	4	Debug Window.....	8
Using a Crystal for the System Clock .....	4	Register Map (Regmap Values) Window .....	8
Using an External Reconstruction Filter .....	4	AD9912 Evaluation Board Reconstruction Filter .....	9
Evaluation Board Software Setup .....	5	Single-Ended Filter Design .....	9
Host PC Requirements .....	5	Differential Filter Design.....	10
Software Installation .....	5	AD9912 System Clock PLL Loop Filter.....	11
Running the Software .....	5		

## REVISION HISTORY

### 3/14—Rev. 0 to Rev. A

Changes to Package Contents and General Description.....	1
Added Online Resources .....	1
Changes to Figure 1 .....	1
Updated Figure 2 .....	3
Changes to Using an Oscillator for the System Clock Section and Using a Crystal for the System Clock Section .....	4
Added Host PC Requirements Section and Table 1; Renumbered Sequentially.....	5
Changes to Software Installation Section.....	5
Removed Ordering Information Section .....	12

### 1/08—Revision 0: Initial Version

## EVALUATION BOARD PHYSICAL CONNECTIONS




Figure 2. AD9912 Evaluation Board, Rev. B

The following instructions are for setting up the physical connections to the AD9912 evaluation board. They assume that the evaluation software has already been installed. The physical connections for Revision A and Revision B of the AD9912 evaluation board are identical.

The following case is used as an example: output frequency: 155.52 MHz; DAC system clock: 1000 MHz input provided on the SYSCLK SMA connector; system clock PLL is disabled.

### POWER CONNECTIONS

1. Connect power and ground to the main power connector labeled TB1, and follow the silkscreen labels describing each power connection.
2. Connect a 1.8 V supply to VDD\_DACDEC (J32).
3. Connect a 3.3 V supply to the following AD9912 SMA connectors: VDD\_DAC3 (J11) and XO\_PWR (J12) (XO\_PWR is only necessary if there is a crystal oscillator mounted on the board).
4. If using the CMOS OUT (J7), power must also be applied to VDDX\_DRV (J9), and R106 must be populated with a 0 Ω resistor. VDDX\_DRV can be either 1.8 V or 3.3 V. Note that the power-on default of the AD9912 is CMOS driver enabled, HSTL driver disabled.
5. Ensure that the S1 to S4 jumpers are tied to VDD. These settings are only for generating 155.52 MHz at startup and register programming overrides these settings.
6. Apply power.

Note that there are two other 1.8 V power connectors, VDD\_DACCLK (J16) and VDD\_DRV/VDD\_FDBK (J17), on the evaluation board. These power supplies are fed by the AVDD supply on connector TB1 when the following 0 Ω resistors are in place (on the back of the board): R9, R10, R23, R60, R63, R64, R65, R66, R19, R22, and R132.

### CONNECTIONS TO PC

1. Connect the USB cables to the evaluation board and the computer. The LED labeled USB on the AD9912 evaluation board should be blinking.
2. See the Evaluation Board Software Setup section for details on running the AD9912 evaluation board software.

### SIGNAL CONNECTIONS

1. Ensure that JMP1 connects VDD to the center pin.
2. Connect the 1 GHz signal generator to SYSCLK (J10). An amplitude setting of 0 dBm to +3 dBm is fine. If a crystal oscillator is used for generating SYSCLK, the SYSCLK (J10) input can be left open.
3. The user has the following four output options on the AD9912:
  - CMOS driver (default): connect an oscilloscope/spectrum analyzer to CMOS\_OUT (J7). Note that R106 must be installed to connect J7 to the CMOS out on the AD9912. Connect DUT FILTER OUT (J5) to FDBK IN (J6). Note that this step is not necessary if R20 (near J5) and R18 (near FDBK IN/J6) are stuffed.

- HSTL driver: put a 50  $\Omega$  terminator on OUTB (J2), and connect OUT (J1) to a spectrum analyzer. Connect DUT FILTER OUT (J5) to FDBK IN (J6). Note that this step is not necessary if R20 (near J5) and R18 (near FDBK IN/J6) are stuffed. Enable the HSTL driver in the evaluation software.
- Filtered DAC output: remove R13, and put a 0  $\Omega$  resistor across R12. Remove R20. Connect a spectrum analyzer to DUT FILTER OUT (J5).
- Unfiltered DAC output: remove R12, and put a 0  $\Omega$  resistor across R13. Connect a spectrum analyzer to DUT OUT/FILTER IN (J4).

### USING AN OSCILLATOR FOR THE SYSTEM CLOCK

1. Solder the 5 mm  $\times$  7 mm oscillator to X4.
2. R101, R102, and R103 may need to be adjusted or removed depending on the oscillator output type. Refer to the evaluation board schematic for details.
3. Install the appropriate system clock PLL loop filter, and remove the 1 k $\Omega$  pull-down resistor on the LF pin. Refer to the evaluation board schematic on [www.analog.com](http://www.analog.com) for details.

### USING A CRYSTAL FOR THE SYSTEM CLOCK

1. Remove C100, C101, and Transformer T5.
2. Solder crystal to X2 or X3, depending on size.
3. Install R104 and R105. 0  $\Omega$  is a recommended starting point, but the user may need to experiment with higher values if the crystal is being overdriven.
4. Refer to the evaluation board schematic for recommended values of C84, C21, and L4.
5. Change JMP1 to straddle the center pin and GND.
6. Install the appropriate system clock PLL loop filter, and remove the 1 k $\Omega$  pull-down resistor on the LF pin. Refer to the evaluation board schematic for details.

### USING AN EXTERNAL RECONSTRUCTION FILTER

1. Install a 0  $\Omega$  resistor at R13, and remove R20 and R18.
2. Connect the single-ended reconstruction filter to J4 and J6.

## EVALUATION BOARD SOFTWARE SETUP

The following instructions are for setting up the [AD9912](#) evaluation board software. The same software can be used for both Revision A and Revision B of the [AD9912](#) evaluation board.

The following case is used as an example: output frequency: 155.52 MHz; DAC system clock: 1000 MHz input provided on the SYSCLK SMA connector; system clock PLL is disabled.

### HOST PC REQUIREMENTS

To successfully use the evaluation board and run the software, the requirements listed in Table 1 must be met.

**Table 1. AD9912A/PCBZ Requirements**

Item	Requirement
Operating System	32-bit Windows® 7/98/ME/2000/XP Note: 64-bit Windows® is supported by running Windows® XP under Windows® Virtual PC
Processor	Pentium® I or later
Memory	128 MB minimum
Ports	One USB port
Clocking	Signal generator capable of generating sinusoidal waves of at least 0 dBm, up to at least 10 MHz
Power Supplies	Capability to generate at least two independent dc voltages (1.8 V/3.3 V)
Measurement	Appropriate measurement device, such as a spectrum analyzer or a high bandwidth oscilloscope
Cables	USB 1.1/2.0 cable and SMA-to-X cables (X = SMA or BNC, depending on the connector of the device interfacing with the board)

### SOFTWARE INSTALLATION

1. Download the [AD9912](#) Evaluation Software by visiting [www.analog.com](http://www.analog.com) and searching **AD9912**.
2. Click the **Evaluation Boards & Kits** link. The [AD9912](#) evaluation software page has links to the evaluation software, as long as schematics and Gerber files.
3. Click the **AD9912 Evaluation Software** link.
4. Double-click the downloaded file to install the software.
5. Follow the installation instructions.

The default location for the evaluation software is  
C:\Program Files\ADI\AD9549\_9912 Eval Software.

### RUNNING THE SOFTWARE

1. If you have not connected your evaluation board yet, refer to the Evaluation Board Physical Connections section.
2. Double-click **AD9549 & AD9912 Evaluation Software**.

3. Run the [AD9912](#) evaluation software, and click the splash screen when the **Software Ready** message is displayed. You will see the **Interactive Block Diagram** window, which is the main window for the software.
4. If you have not yet connected your evaluation board, you will be prompted to choose [AD9912](#) or [AD9549](#) evaluation board. Click **AD9912 Evaluation Board**.

Note that Windows will indicate **Found New Hardware** the first time you connect the evaluation board. Nothing special needs to be done when this happens, and Windows will install the software driver. It may be necessary to disconnect and reconnect the USB cable after this happens.

5. In the lower left corner of the window, look for **Ezssp-0**, **Ezssp-1**, or **Ezssp-2** in green letters. This indicates that the software has found and connected to the evaluation board. If you see **not connected**, the software cannot locate the evaluation board. Try selecting **Select Evaluation Board** from the **I/O** menu and see if **Ezssp-0**, **Ezssp-1**, or **Ezssp-2** can be selected. If not, check your cable connections, power cycle the board, and rerun the software to remedy this problem.
6. The main window is the **Interactive Block Diagram** window. Click the **Reset** button at the top of the **Interactive Block Diagram** window.
7. If you have a setup file, click **Load Eval Board Setup** at the top of the window and select the desired setup .STP file.
8. If the reference frequency that is provided to the system clock input is different from 25 MHz, click the **DDS** box, and enter the frequency in the **External Clock** box. This is critical because the evaluation software relies on the correct system clock in order to calculate the various frequencies used on the [AD9912](#).
9. You should now see the 155.52 MHz output. If HSTL output on Connector J1 and Connector J2 are desired, enable the 1.8 V HSTL driver by clicking the triangle inside the dashed box in the **Interactive Block Diagram** window.
10. If the CMOS driver is not being used, it can be powered down by clicking the triangle inside the dashed box in the **Interactive Block Diagram** window.

See the Evaluation Software Main Window section for a description of the main window features, or see the Evaluation Software Functional Blocks section for details on the individual blocks of the [AD9912](#).

## EVALUATION SOFTWARE MAIN WINDOW




Figure 3. AD9912 Interactive Block Diagram

The main window of the evaluation software consists of three major areas: the menu bar, the button bar, and the window display area. The window display area is where windows such as the **Interactive Block Diagram** window appear.

Note that the AD9549 and AD9912 share the same evaluation software. If the evaluation board is not found, the software prompts the user to select which evaluation board will be connected.

Access to the individual components and features of the AD9912 can be accomplished in two ways. The user can click a given block from the **Interactive Block Diagram** window, and that block's own window will open. The same window can also be accessed from the **Window** menu in the menu bar.

### INTERACTIVE BLOCK DIAGRAM

The **Interactive Block Diagram** window shows all of the major blocks of the chip, and clicking a block, such as DDS, brings up a window where the user can change the settings for that block. It displays the current settings for the entire chip, such as input and output frequency, system clock, reference selected, and the status of the S1 to S4 pins.

Figure 3 shows the default condition for S1 to S3 = 1, and S4 = 0.

### MENU BAR

#### File Menu

##### Load Evaluation Setup File/Save Evaluation Setup File

Identical to selecting the **Load Eval Board Setup/Save Eval Board Setup** buttons on the button bar, this loads/saves an AD9912 setup file (.STP). A setup file is a text file that contains the AD9912 register setup file, plus any evaluation board settings.

Note that when saving register setup files, it is important to select single-tone mode before saving the file. Register setup files are loaded into the AD9912 sequentially, and the loop should only be locked once all registers are loaded. Otherwise, the part may need to be reset.

#### Options

Allows the user to control whether the software polls the evaluation board. The startup log can also be viewed by clicking **View Startup Log** from this window.

#### Exit

Exits the evaluation software. No checking is done to ensure that the existing setup is saved.

### ***I/O Menu***

#### **Select Evaluation Board**

The [AD9912](#) evaluation system allows one PC to control multiple evaluation boards. This command allows the user to select which evaluation board the software controls.

#### **DUT I/O Configure**

This command selects 3- or 4-wire serial port mode, LSB first, and contains a button for a soft I/O reset.

#### **Window Menu**

This menu allows the user to select any of the 14 windows that are associated with the major functional blocks of the [AD9912](#). These windows are also accessible by going to the **Interactive Block Diagram** window and clicking the block of interest. See the Evaluation Software Functional Blocks section for a description of each of these windows.

#### **Help Menu**

Selecting **Help** brings up the **About AD9912** splash screen. It contains information such as revision number, region information, and contact information.

### **BUTTON BAR**

The following buttons are provided for easy access to common features.

#### ***Load Eval Board Setup/Save Eval Board Setup***

These buttons allow the user load/save an [AD9912](#) setup file (.STP). A setup file is a text file that contains the [AD9912](#) register setup file, plus any evaluation board settings.

Note that when saving register setup files, it is important to select single-tone mode before saving the file. Register setup files are loaded into the [AD9912](#) sequentially, and the loop should only be locked once all registers are loaded. Otherwise, the part may need to be reset.

#### ***Reset***

This button resets the evaluation board and restores the [AD9912](#) to its default power-up state.

#### ***I/O Update***

This button toggles the IO\_UPDATE pin on the [AD9912](#).

#### ***Block Diagram***

This button selects the **Interactive Block Diagram** window.

#### ***Debug Window***

This button selects the **Debug** window. See the Debug Window section for a description.

## EVALUATION SOFTWARE FUNCTIONAL BLOCKS

The [AD9912](#) evaluation software is made up of subsections that correspond to the [AD9912](#)'s major functional blocks. These subsections are listed in the following sections, and each of these has its own window.

The main window is the **Interactive Block Diagram** window, and from it, the window for each functional block can be accessed by clicking that block. The user can also access each of these windows from the **Window** menu at the top of the window.

Each window has a check box labeled **Auto I/O Update**. If this box is checked, the software performs an I/O update operation any time there is a setting change in that box.

For convenience, some detailed information from the [AD9912](#) data sheet is included here. In cases where there is an inconsistency between this document and the [AD9912](#) data sheet, assume that the data sheet is correct. Please inform us of this inconsistency so that it can be corrected.

### INTERACTIVE BLOCK DIAGRAM

The **Interactive Block Diagram** (IBD) window shows all of the major blocks of the chip, and clicking a block, such as **DDS**, brings up a window where the user can change the settings for that block.

### S-DIVIDER SETTINGS WINDOW

Clicking the **S-Divider** box brings up the **S-Divider Settings** window.

This window is used for setting the output divider for the CMOS output and for setting the divide-by-2 prescaler. Note that this bit must be set if the signal present on `FDBK_IN` is 400 MHz or greater.

### DDS AND CLOCK MULTIPLIER CONTROL

Clicking the **DDS** and **Clock Multiplier** box brings up the **DDS and Clock Multiplier** window. This window is used to set up the system clock PLL and is frequently used. It contains two tabs: **DDS** and **Harmonic Spur Reduction**.

The **DDS** tab has three sections: **DDS Clock**, **DDS Settings**, and **DAC Control**.

In the **DDS Clock** section of the tab, the frequency of the external clock source driving the system clock is entered into the box labeled **External Clock**. The default is 25 MHz. If the system clock is supplied directly, be sure to put a check in the **Bypass Multiplier** check box.

If the system clock PLL (SYSCLK PLL) is to be used, enter the desired multiplication factor. The multiplier value in the panel does not factor in the bipolar edge detector. Therefore, if an overall multiplication factor of 40 is desired when using the bipolar edge detector,  $\times 20$  should be entered for the multiplier.

It is recommended to put a check in the **Auto Range** check box. This is especially true for system clocks in the 800 MHz to

900 MHz range. Refer to the [AD9912](#) data sheet on the use of VCO Auto Range.

The charge pump current of 250  $\mu\text{A}$  (default) is fine for most applications, but it can be adjusted here if desired.

The **Clock Multiplier** section has an  $\times 2$  **Reference** check box, and it controls the bipolar edge detector of the system clock PLL. This frequency doubler can reduce the in-band jitter of the system clock PLL, and it is described in detail in the [AD9912](#) data sheet. When this box is checked, the multiplier must be cut in half to maintain the same overall frequency multiplication.

The desired output frequency is entered in the **DDS Settings** section. Note that loading the DPLL settings that are generated using `FilterDesign.xls` automatically sets the output frequency calculated in `FilterDesign.xls`. The primary value of entering an output frequency here is to set up single-tone mode without having to configure the DPLL loop filter. The **DDS Settings** section also features a place to enter a static phase offset. Bear in mind that this static phase offset is not active when the DPLL loop is closed.

**DAC Control** is the last section of the **DDS** tab. The **DDS DAC** current can be altered here. However, the default values are recommended, and these values are not normally altered. Increasing the DAC current increases the output amplitude but can degrade the harmonic performance of the DAC. One case where this might be useful is when using a SAW filter because they can have high insertion loss.

### CMOS DRIVER AND CLOCK OUT

Clicking the mux symbol near the CMOS output driver in the **Interactive Block Diagram** window brings up the **CMOS Driver and Clock Out** window. Features that are accessed here include the CMOS output divider, HSTL driver power-down, and the HSTL output doubler.

### STATUS AND IRQ CONTROL WINDOW

This feature is not applicable to the [AD9912](#).

### DEBUG WINDOW

Clicking the **Debug** button at the top of the evaluation software window brings up the **Debug** window. This is a legacy window, and the user should not normally need to access it.

The **Serial I/O** section of this window provides a handy way to read and write registers directly.

**Quick Edit** provides an easy way to get a quick look at the **DPLL Registers and Settings**. This includes the digital loop filter coefficients, the dividers, and the frequency tuning word.

### REGISTER MAP (REGMAP VALUES) WINDOW

Clicking **RegMap Values** in the **Window** menu brings up the **Register Map** window. This is a handy text window for quickly viewing the register map.

## AD9912 EVALUATION BOARD RECONSTRUCTION FILTER

Revision A of the AD9912 evaluation board has a 240 MHz low-pass reconstruction filter that is shown in Figure 4. Revision B has a 400 MHz low-pass reconstruction filter. This filter is implemented as a single-ended filter with a transformer on both sides to convert to/from a differential configuration. The transformer used is a Mini-Circuits ADTT-1, and its -3 dB bandwidth is approximately 0.3 MHz to 300 MHz.

### SINGLE-ENDED FILTER DESIGN

The single-ended design with transformers is less susceptible to component variation and is strongly recommended for cases where the cutoff frequency must be tightly controlled, or in designs using a pass-band reconstruction filter. See the AD9912 evaluation board schematic for the exact circuit implementation.

#### 7<sup>th</sup> Order Single-Ended Low-Pass Elliptical Filter (Rev. A)

- Pass-band frequency: 240 MHz
- Pass-band ripple: 0.1 dB
- Stop-band ratio: 1.3
- Stop-band frequency: 312 MHz
- Stop-band attenuation: 60 dB

### Location of Filter Components on Evaluation Board

Note that when the on-board reconstruction filter is bypassed, R12 is removed. R13 is installed and the output is on Connector J4. The following values are for the 240 MHz reconstruction filter:

- 9 pF shunt capacitor: C11 = 4.7 pF in parallel with C80 = 4.7 pF
- 20 pF shunt capacitor: C4 = 10 pF in parallel with C36 = 10 pF
- 23 pF shunt capacitor: C2 = 12 pF in parallel with C28 = 12 pF
- 14 pF shunt capacitor: C3 = 6.8 pF in parallel with C14 = 6.8 pF
- 1<sup>st</sup> LC combination: C1 = 8.2 pF, L3 = 27 nH
- 2<sup>nd</sup> LC combination: C10 = 4.7 pF, L2 = 39 nH
- 3<sup>rd</sup> LC combination: C5 = 1.5 pF, L1 = 47 nH




Figure 4. AD9912 Evaluation Board 240 MHz Single-Ended Reconstruction Filter




Figure 5. Frequency Response of Single-Ended Reconstruction Filter Shown in Figure 4

**DIFFERENTIAL FILTER DESIGN**

The differential filter advantages include fewer components and a simpler design when the AD9912 is used in an actual design. Note that the 100 Ω differential source impedance is internal to the IOOUT/IOUB driver. Also, note that the ac coupling between the IOOUT differential pair and the FDBK\_IN differential pair is critical. Component matching between the corresponding LC sections is important in this design. The example shown in Figure 6 is for a cutoff of 240 MHz.

**7<sup>th</sup> Order Elliptical Differential Low-Pass Filter**

- Pass-band frequency: 240 MHz
- Pass-band ripple: 1.0 dB
- Stop-band ratio: 1.3
- Stop-band frequency: 312 MHz
- Stop-band attenuation: 70 dB




Figure 6. Differential Low-Pass Reconstruction Filter




Figure 7. Frequency Response of Differential Reconstruction Filter Shown in Figure 6

## AD9912 SYSTEM CLOCK PLL LOOP FILTER

The [AD9912](#) system clock PLL has an external loop filter whose components are tailored for different applications.

If the system clock PLL is bypassed, the LOOPFILTER pin should be pulled down to ground with a 1 k $\Omega$  resistor.

The loop bandwidth of the SYSCLK multiplier PLL can be adjusted by means of three external components, as shown in Table 2. The nominal gain of the VCO is 800 MHz/V. The recommended component values and their locations on the evaluation board are shown in Table 2. They establish a loop bandwidth of approximately 1.6 MHz with the charge pump current set to 250  $\mu$ A. The default case is N = 40 and assumes a 25 MHz SYSCLK input frequency and generates an internal DAC sampling frequency ( $f_s$ ) of 1 GHz.

When modeling the [AD9912](#) system clock PLL, bear in mind that there is approximately 5 pF of parallel capacitance internal to Shunt C (C88). The values in Table 2 are the actual values

that should be used on the board and do not include this internal capacitance.

The [AD9912](#) features a bipolar edge detector that doubles the rate of the clock going into the system clock PLL. The multiplication factors in Table 2 are for the system clock PLL only. Refer to the [AD9912](#) data sheet for more details on the system clock PLL and bipolar edge detector.

**Table 2. Recommended SYSCLK PLL Loop Filter Values**

<b>SYSCLK Multiplier</b>	<b>Series R (R98)</b>	<b>Series C (C83)</b>	<b>Shunt C (C88)</b>
8 (or less)	390 $\Omega$	1 nF	82 pF
10	470 $\Omega$	820 pF	56 pF
20	1 k $\Omega$	390 pF	27 pF
40 (default)	2.2 k $\Omega$	180 pF	10 pF
60	2.7 k $\Omega$	120 pF	5 pF

## NOTES

---

### Legal Terms and Conditions

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the "Evaluation Board"), you are agreeing to be bound by the terms and conditions set forth below ("Agreement") unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you ("Customer") and Analog Devices, Inc. ("ADI"), with its principal place of business at One Technology Way, Norwood, MA 02062, USA. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI. ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed.